
VOLUME WITH PUSH-PULL POT FOR ACTIVE/PASSIVE SWITCHING ON AGUILAR OBP PREAMPS

IN NORMAL (DOWN) POSITION, PREAMP IS ENGAGED. IN UP POSITION, PREAMP IS BYPASSED.



GROUND TO CASING ON VOLUME POT AND THEN ONTO JACK GROUND.



www.bestbassgear.com - sales@bestbassgear.com